

DVR VMC VIDEO EXPORT SD CARD DOWNLOAD FAQ

KOHLTECH Video Management Center (VMC) must be installed on computer for viewing and export of DVR video/GPS files, Unless files are exported in MP4 format which can be viewed with media player.

SD Card Download

1. Remove SD Card from DVR (single in R6/8 models, SD1 or SD2 in R5 model)
2. Insert SD Card into computer
3. Open VMC Type: Local, User: admin, Password: blank
4. Double click the appropriate SD Card from Directory on left hand side of VMC which opens a calendar below Directory.
5. Dates on calendar that are green have recorded data. Dates that are blue have no data.
6. Double click on desired green date to load video and GPS data
7. Click scissor icon located above timeline
8. Set desired Start and End times
9. Click OK to open Clip Settings window
10. Confirm Start Time and End Time, select desired channel(s),
11. Highlight Export box to export Video AND GPS data viewable only using VMC software
12. Highlight MP4 to export ONLY Video viewable using MP4 players - www.videolan.org
13. Choose Path: ie. DESKTOP or folder to export to
14. Leave Password blank unless
15. Highlight Main Stream box
16. Click OK to export files

SSD Download

